


Bag-Pressure simulator



chamer connector

audio out (mini + large jack)
 midi in/midi out
 program
 battery lcd indicator
 dc in
 on/off switch



cancel
(drones off)

accept
(drones on)

up
(half tone up)

down
(half tone down)



tone-hole sensors

Chanter Front View



backlit lcd display

bag connector

back d tone-hole sensor

thumb controlled keypad for menu options

thumb rest area

bottom tone-hole sensor

Chanter Rear View